How to copy a procedure to another surface?

Right click the procedure’s name and choose Copy. Right click the other surface’s name and choose Paste inside. Then expand the copy and check its settings.

Revision #2
Created 2026-11-23 11:29:15 UTC by eCare Content Studio
Updated 2026-11-23 15:27:08 UTC by eCare Content Studio